

Relevant Reading Assignments

- Chapter 9 of "Introduction to Nuclear Engineering," Lamarsh and Baratta, 3rd edition, Prentice-Hall (2001)
- Chapter 3 of "Nuclear Engineering: Theory and Technology of Commercial Nuclear Power," Knief, 2nd edition, American Nuclear Society (1992, reprint by ANS 2008)

Learning Objectives

 Identify the major purposes of reactor shielding and explain secondary radiation.

Radiation Shielding

- Purpose of radiation shielding
 - Protect personnel and/or equipment ("behind" the shield) from radiation exposure
 - Absorb *primary radiation* incident on the shield
 - Reduce primary radiation energy (usually through scattering) to produce secondary radiation that is less damaging / easier to absorb.
 - Absorb secondary radiation generated within the shield material.

Shielding Effects


- Radiation Buildup
 - Absorption/scattering collisions
 - Secondary radiations
- Secondary Radiation
 - Scattered gamma rays
 - Compton scattering
 - Capture gamma rays
 - Neutron capture (n, γ)
 - Secondary radiation can dominate over primary radiation

Radiation Shielding


- Alpha / beta radiation
 - Short range, small thickness of any material will work.
 - Requires only simple shielding (Layer of skin / piece of foil).
- Gamma / neutron radiation
 - Extremely penetrating, reaction rates are highly material dependent (preferred shielding materials).
 - Shielding
 - Have to worry about both primary and secondary radiations
 - Usually requires composite shields containing several different materials.

Radiation Shield Types

- Simple
 - Lead "Hazardous" (toxic), so handle carefully
 - ConcreteGeneral Purpose
 - Water Research Reactor "Pool"
- Composite (for mixed n, γ radiations)
 - Optimize gamma & neutron attenuation
 - Minimize thickness / weight
- Specialized shields
 - "Lead" Glass for use in shielded "hot cells" that workers must see inside of.



Composite Shield



Shield Attenuation

- Tenth thickness (also called "tenth-value layer")
 - Approximate amount (cm or in.) of a specific material required to reduce radiation dose by a factor of 10 (i.e., to 1/10th)
 - Materials have different values for each type of radiation.
 - Each tenth thickness provides a factor of ten reduction
 - For example: six (6) tenth thicknesses provide $10^6 = 1,000,000 = 1$ million reduction factor

Shield Attenuation

$$\frac{1}{I_0} = \left(\frac{1}{2}\right)^{\left[\frac{x}{X_{1/2}}\right]}$$
 Half thickness attenuation formula

$$\frac{1}{I_0} = \left(\frac{1}{10}\right)^{\left[\frac{x}{X_{1/10}}\right]}$$
 Tenth thickness attenuation formula

- Intensity
- Distance (Thickness of Shield)

$$X_{1/10}$$
 X_{TT} Tenth Thickness [cm] $X_{1/2}$ X_{HT} Half thickness [cm]

Tenth Thickness Values

TENTH THICKNESSES (XTT) FOR MATERIALS USED FOR RADIATION SHIELDING

		Tenth Thickness [cm]		
Material	Density [g/cm³]	Fast Neutrons	Gamma	
			1 MeV	Reactor (w/ Buildup)
Water	1.0	23	34	69
Graphite	1.62	21		44
Ве	1.85	21		42
BeO	2.3	21		32
Concrete	2.3-4.3	38-14	17-11	34-18
Al	2.7	23	14	30
Iron	7.8	14	5.1	8.5
Lead	11.3	21	2.9	5.8
Glass	2.7-6.2		15-5.6	
Air	0.0011		0.88 km	

Source: Etherington, 1958